



***EXTREME CAUTION NEEDS TO BE EXHIBITED DURING INSTALLATION. REFER TO DETAILED INSTRUCTIONS BEFORE INSTALLATION BEGINS.**

NOTE:
 POWER WIRES SHOULD BE ROUTED IN SEPARATE CONDUIT FROM CONTROL CABLE.
 SUGGEST 1/2" CONDUIT FOR POWER AND CONTROL.

VENTILATION- INSTALL SCOREBOARD SO AIRFLOW IS NOT RESTRICTED FROM BACK.